

Device Lubrication

The Detex device you have purchased is delivered to you properly lubricated with a multi-purpose synthetic grease. It is strongly recommended that all mechanical parts and surfaces of the device be periodically lubricated, inspected, and tested.

Before lubricating, remove/clean any foreign material from area to be lubricated. Apply enough lubricant to assure penetration between moving parts.

Detex uses **NS-10895-G**, manufactured by **Syn-Tech**.

See the diagrams below for recommended points of lubrication. These are subassemblies typically found in a disassembled exit device.



